

# THE RIGHT FLATBED THE RIGHT PRICE



4 OR 6 PRINTHEADS

UP TO 3.74" OF  
HEIGHT CLEARANCE

CMYK OR  
CMYK+WH+GL

## HQ

### High Productivity, High Quality

- ▶ Print up to nine 4'x8' boards per hour in CMYK, or print four 4'x8' boards per hour in CMYK+Wh using standard mode.
- ▶ Variable dot printing technology and True Rich Color preset combine precision droplets with vivid and natural color to give you the best print output.



### Direct-to-Object Versatility

- ▶ Print directly to full 4'x8' boards for large signs, displays, and other professional graphics.
- ▶ A maximum print height of 3.74" gives you room to work with unique substrates.
- ▶ Print onto acrylic, wood, PVC, PETG, foam, aluminum plate and more.

## UF

### User Focused Features

- ▶ Built in sensors and emergency stops provide increased operator safety.
- ▶ Greenguard Gold Certified inks are low VOC and safe for indoors.
- ▶ Includes SAI FlexPRINT Plus Roland DG Edition RIP Software.
- ▶ 12 Month Manufacturers Warranty including print heads.

## Additional Features

- + Print at a lower cost with ink that's economical compared to other large format UV flatbed inks on the market.
- + Liquid cooling increases LED lamp lifespan while improving print curing processes.
- + Add Gloss textures, raised embossed effects, and spot varnish for stunning finishes.
- + Industrial Grade Casters and Levelling Adjusters ensure secure machine placement for production and allow you to move the machine if necessary.
- + Easy ink loading allows you to refill 2.5-liter ink tanks on-the-fly for high volume print productivity.
- + 4-zone electronic vacuum bed automatically adds air suction and support in specific areas.

## Technical Specs

		<b>EU-1000MF</b>
<b>Media</b>	<b>Width</b>	Max. 96 in. (2,440 mm)
	<b>Length</b>	Max. 48 in. (1,220 mm)
	<b>Thickness</b>	Max. 3.74 in. (95 mm)
	<b>Weight</b>	Max. 99 lb./m <sup>2</sup> (45 kg/m <sup>2</sup> )
	<b>Max. printing width/printing length (*1)</b>	Max. 96 x 44 in. (2,440 mm x 1,120 mm)
<b>Ink</b>	<b>Type</b>	E-US
	<b>Colors</b>	6 colors (Cyan, Magenta, Yellow, Black, White, Gloss)
	<b>Tank Capacity</b>	2.5 L
	<b>Bottle Capacity</b>	1-Liter Bottles
	<b>Configurations</b>	4-Color CMYK 6-Color CMYKWhGI
<b>Machine Weight</b>		2,970 lb. (1,300 kg)
<b>Resolution</b>		Max. 720 x 1,200 dpi
<b>RIP (included)</b>		SAI FlexiPRINT Plus Roland DG Edition

\*1 The maximum printing area can be extended to 96 x 48 in. (2,440 x 1,220 mm).



Built to build your business and engineered to a higher standard, the EU-1000MF is supplied with a One-Year Trouble-Free Warranty for added peace-of-mind.

For more information or to find a dealer near you, call 800.542.2307 or visit [www.rolanddga.com/EU-1000MF](http://www.rolanddga.com/EU-1000MF)  
 Roland DGA Corporation | 15363 Barranca Parkway | Irvine, California 92618-2216 | 800.542.2307 | 949.727.2100

  
 RDGA-EU-1000MF-02 MARCH 2024